


CONSPICUITY TAPE WILL BE SUPPLIED WITH ALL TRAILERS 10,000 GVWR AND ABOVE. APPLY THE TAPE TO THE REAR CROSSMEMBER, TONGUE AND BOOM. DUE TO THE VARIOUS CHASSIS LOCATIONS, IT WILL BE NECESSARY TO FIT TAPE AS NOTED ABOVE. TAPE MUST COVER AT LEAST 50% OF THE LENGTH OF TRAILER IN ALTERNATING COLORS.

- 1) ALWAYS START AT THE REAR OF THE TRAILER (NEXT TO THE TIE DOWN) WITH RED. IF THERE IS ONLY ROOM FOR ONE COLOR IN THIS SECTION, ALWAYS USE RED. NO TAPE MAY BE LOCATED CLOSER THAN 3" TO ANY LIGHT OR REFLECTOR.
- 2) START THE NEXT SECTION OF TAPE 3" IN FRONT OF THE STEP AND COVER AS MUCH OF THE BOOM AS POSSIBLE.
- 3) THE TAPE ON THE TONGUE WILL BE CENTERED BETWEEN THE WIRE HOLES AND WILL COVER AS MUCH OF THE TONGUE AS POSSIBLE. NO TAPE CAN BE CLOSER THEN 3" TO THE AMBER LIGHT. TAPE CAN BEGIN AND END WITH EITHER WHITE OR RED.
- 4) FOR THE CROSSMEMBER CENTER THE TAPE BETWEEN THE CROSSMEMBER HANGER AND THE THREE LIGHT BAR AS SHOWN. NO TAPE MAY BE LOCATED CLOSER THAN 3" TO ANY LIGHT

WARNING:

EACH COLOR OF CONSPICUITY TAPE WHETHER IT BE RED OR WHITE IS REQUIRED TO BE A MINUM OF 2" HIGH AND 6"-18" LONG

★ INDICATES CHANGE ON EFFECTIVE DATE

DESCRIPTION: CONSPICUITY TAPE INSTRUCTIONS		PART #: CONSPICUITY TAPE	
EFFECTIVE DATE: 09-22-11		ECN:	DWG BY:
		PROPRIETARY AND CONFIDENTIAL INFORMATION	